

## TAL DIY Tiling budget planner

Description	Details	Cost
Size of area to be tiled	Multiply the dimensions of the room to get the number of square metres  _____ m wide x _____ m long = _____ m <sup>2</sup>	
Add 10-20% to total for cuts and breakages and as spare stock	_____ m <sup>2</sup> x R _____ /m <sup>2</sup>	
Cost of tiles	_____ m <sup>2</sup> x R _____ /m <sup>2</sup>	<b>R</b>
Tile Adhesive required (See adhesive selection guide to ensure you have the right adhesive for the tiles selected)	Approximate coverage of adhesive:  Wall: _____ m <sup>2</sup> x 3kg/m <sup>2</sup> = _____ kg Divide by 20 = _____ 20kg bags  Floor: _____ m <sup>2</sup> x 6kg/m <sup>2</sup> = _____ kg Divide by 20 = _____ 20kg bags  Add 10% for waste _____	<b>R</b>
Grout required	Use the TAL Grout calculator, enter the length, width and thickness of your chosen tile in mm  _____ kg grout x R _____ /bag	<b>R</b>
<b>Optional extras depending on where you are tiling:</b>		
Priming System: Smooth or dense surfaces e.g. powerfloated concrete/ screed or existing tiles	A 20kg TAL Keymix + 10L TAL Keycoat slurry coat will cover approximately 35-40m <sup>2</sup>  _____ m <sup>2</sup> / 35m <sup>2</sup> = _____ slurry 'kits' of 20kg TAL Keymix + 10L TAL Keycoat (sold separately)  Note: TAL Keymix is available in 5kg bags for smaller areas. Mixed with 2.5L TAL Keycoat, the slurry will cover approximately 8-10m <sup>2</sup>	<b>R</b>
Additive to tile adhesive and grout (Required if you are tiling a bathroom or kitchen, upstairs or an outside area)	Use TAL Bond as a total water replacement in the adhesive and grout mix. Refer to the adhesive packaging or data sheet for the correct mix ratios. Alternatively, you can add TAL Bond Powder to the adhesive and grout mixing water, at a rate of 1 x 1kg sachet per 20kg bag of adhesive or grout.	<b>R</b>

<p>Waterproofing system (Required if you are tiling a shower, balcony or other wet area)</p>	<p>10 - 12m<sup>2</sup> per 20kg TAL Sureproof kit at 2mm thick cured film. NB : You will need to order TAL Sureproof Membrane as reinforcing for all internal corners and interfaces, around drains/wastes and plumbing fittings, etc. This is available in 200mm x 10m rolls.</p> <p>_____ m<sup>2</sup> ÷ 10m<sup>2</sup> = _____ kits</p> <p>_____ kits x R _____ / kit = R _____</p>	<p><b>R</b></p>
<p><b>Total cost of installation products</b></p>		<p><b>R</b></p>
<p>Labour – if you have decided to use a tiler</p> <p>_____ m<sup>2</sup> x R _____ / m<sup>2</sup> = R _____</p>		<p><b>R</b></p>
<p>Tiling Tools for DIY installation</p>	<p>Adhesive trowel Mixing paddle Grout squeegee Grout Sponge Spacers Tile Nipper Tile Cutter Rubber Mallet</p>	<p><b>R</b></p>
<p><b>Total cost of project</b></p>		<p><b>R</b></p>