

High performance primer for epoxy coating and floor systems

Product Description

TAL SF PRIMER is a high penetration primer suitable for use with a wide range of epoxy coatings and floor systems.

Advantages

- Meets SCAQMD Rule 1113 & LEED VOC Limits
- Formaldehyde free
- Low viscosity
- Solvent free
- Penetrating
- Enhances bond
- Stops out gassing

Specification Compliance

SCAQMD Rule 1113
LEED NC2009 IEQ 4.2

Laboratory Test Data

Property	Typical Results
Volume solids	100%
Specific gravity	1.05 ± 0.05
Pot life	60 mins at 30°C (86F)
Touch dry	3 hours at 30°C (86F)
Recoat time	6 to 24 hours at 30°C (86F)

Volatile Organic Content

VOC = 0 g/L

Theoretical Coverage

TAL SF PRIMER 10m² per liter (110ft² per quart). Actual coverage will depend on wastage and surface profile and can be up to 30% or more higher than theoretical coverage.

Packaging

5 and 15 liter packs

Shelf Life

18 months when stored at below 30°C under shade in a dry environment.

Installation Guidelines

Epoxy coating and floor systems should be applied by experienced coating crews. TAL provides detailed method statements on all its products for use in various applications. These must be referred to prior to starting work. The information below is a summary intended for guidance only.

Surface Preparation

The substrate must be structurally sound. Loose or unsound concrete should be removed and made good. Surfaces must be entirely free of oil, grease, paint, corrosion deposits, dust, laitance or other surface deposits. The surface should be prepared by captive blasting to produce a lightly exposed aggregate surface i.e. a ICRI CSP 4 or 5 surface profile. Any bug holes (blow holes) should be filled with TAL BUGFILL or TAL PRIMER FILLER.

Moisture Testing

The concrete slab should be tested for moisture with the Rapid RH system following the procedure in ASTM F2170. If the humidity reading is greater than 80% then conduct moisture vapor emission rate (MVER) testing using the procedure in ASTM F1869. (Both test kits are available for purchase from TAL). If the MVER is under 3lbs/1000ft²/24h use TAL SF PRIMER. If the MVER is 3 to 5 lbs/1000ft²/24h use a single coat TAL MT PRIMER at 165 microns wft. If the MVER is 5 to 12 lbs/1000ft²/24h use two coats of TAL MT PRIMER at 200 microns wft per coat.

Mixing

Mix TAL SF PRIMER using the following technique. Add the hardener 'Part B' into the base 'Part A' and mix using a slow speed drill (500 rpm) with an Coating Mixer Paddle for 3 minutes or until both components have fully dispersed and are uniform in color. Be sure to rotate the mixer throughout the drum. Mix only full packs.

Application

Apply a single coat of 100 micron (4mils) wet film thickness using brush, roller or airless spray. When using airless spray, tip size should be 0.015" to 0.0018" at a pressure of 2200psi. Allow to dry before over coating. Ensure that no ponding of the primer occurs and that it is not applied too thick. Recoat after 6 to 24 hours at 30°C (86F). If the primer is left to dry for more than 24 hours the surface will have to be re-primed. Porous substrates may require a two coat application. Clean equipment using TAL SOLVENT S.

Limitations

Will not accommodate movement cracks.
Do not be apply within 3°C of the dewpoint or if it is within 5°C of the dewpoint and dropping.
Avoid excessive application.
Avoid skin contact.
Do not discard into the water system.

